

Technical Note

Title: Sound Card Failure
Date: 09/28/95
Product Fields: 400 / Satellite Pro
Failure

Toshiba America Information Systems, Inc. has done its best to ensure the accuracy of this information. Toshiba America Information Systems, Inc. reserves the right to revise or make obsolete some or all of the contents without obligation to notify any person of such revisions or changes. Despite every effort to the contrary, errors, omissions or discrepancies may have occurred in preparation of this document and Toshiba America Information Systems, Inc. assumes no liability for damages incurred due in part or in whole to such errors.

PROBLEM

After running a Windows sound program (like the MagiCD demo), the system will not play any more sounds , warning the sound device is not working properly.

SOLUTION

Use the following commands to restore the WIN.INI and SYSTEM.INI from the pre-install, then test the sound card again.

In the Windows Directory:

1. "COPY SYSTEM.INI SYSTEM.BAD"
2. "TYPE C:\TAIS.PS\SYSTEM.INI > SYSTEM.INI 3. "COPY WIN.INI WIN.BAD"
4. "TYPE C:\TAIS.PS\WIN.INI > WIN.INI"

Keywords

SOUND PC AUDIO