MAP 3100: Alternate PC Network Adapter

Symptom Explanation	Conditions That Could Cause This Symptom
You have entered this MAP because you have a 31XX error code, IO ROM CC0000, CC0000 ROM error, or have identified an Alternate PC Network Adapter failure.	 The alternate PC Network Adapter is failing. The PC Network is failing.

001

Ensure the covers are installed before running this test.

- Run the Alternate PC Network Adapter tests. Use the (RUN TESTS MULTIPLE TIMES) option.

DID YOU RECEIVE AN ERROR CODE?

Yes No

| 002

You have successfully completed the Advanced Diagnostic tests. If you suspect an intermittent problem, or are having network problems, refer to the service manual for the PC Network.

003

DID YOU RECEIVE A 3115 OR 3141 ERROR CODE? Yes No

| 004

Go to Step 006 in this MAP.

005

(Step 005 continues)

006

(From Step 004 in this MAP) DID YOU RECEIVE A 3120 ERROR CODE? Yes No | |

007 Replace the Alternate PC Network Adapter.

008

ARE TWO PC NETWORK ADAPTERS INSTALLED? Yes No

| 009

Replace the PC Network Adapter.

010

Determine which PC Network Adapter has jumper W8 enabled (set to the On position) and replace the adapter.