

Technical Note

Title: 700 hangs during shut down in Windows 95

Date: 04/08/96

Product Fields: 700 / Tecra
Operating System

Toshiba America Information Systems, Inc. has done its best to ensure the accuracy of this information. Toshiba America Information Systems, Inc. reserves the right to revise or make obsolete some or all of the contents without obligation to notify any person of such revisions or changes. Despite every effort to the contrary, errors, omissions or discrepancies may have occurred in preparation of this document and Toshiba America Information Systems, Inc. assumes no liability for damages incurred due in part or in whole to such errors.

PROBLEM

When shutting off Windows 95 on a 700 the system will lock up at the "Please wait while the computer shuts down" logo screen.

SOLUTION

Disable the two transit files in the [386enh] section in the SYSTEM.INI file. The two lines are :

```
device=C:\TRANXIT\PCOMM2.386 '  
    and  
device=C:\TRANXIT\PUMAIR.386.
```

This seems to happen when the computer is upgraded to Window 95 from Windows 3.XX.

Keywords

TRANXIT WINDOWS 95 HANGS LOCKS SHUT DOWN shutdown irda